

Machine learning and data analysis at the ZeMA condition monitoring testbed


Tanja Dorst

Digital technologies in industrial measurements

September 24th, 2021

ZeMA testbed for electromechanical cylinders

- Testbed for condition monitoring, lifetime prognoses and end-of-line tests of electromechanical cylinders (EMCs) with a spindle drive
- Long-time high load and speed driving tests until a position error of the EMC occurs
- Relevant sensors and characteristic signal patterns can be identified for condition monitoring and remaining useful lifetime (RUL) estimation of the EMC
- Simplified installation
 - Tested EMC
 - Pneumatic cylinder (simulates the load on the EMC in axial direction)




Source: Festo AG & Co. KG

High-quality measurement system at ZeMA testbed


- Working cycle consists of forward stroke, waiting time and return stroke
- Sensor technology (sampling rate) ^[1]
 - Three motor current sensors (each 1 MHz)
 - Three acceleration sensors (each 100 kHz)
 - at the ball bearing
 - at the plain bearing
 - at the piston rod
 - One ultrasonic microphone (100 kHz)
 - Four process sensors (each 10 kHz)
 - Axial force
 - Velocity
 - Pneumatic pressure
 - Active current

Velocity	200 [mm/s]
Axial force	7 [kN] (const. pulling)
Acceleration / Deceleration	5 [m/s ²]
Stroke range	100 to 350 [mm]
Waiting time	150 [ms]
Cycle length	2.8 [s]



[1] T. Schneider, N. Helwig, S. Klein, and A. Schütze, "Influence of Sensor Network Sampling Rate on Multivariate Statistical Condition Monitoring of Industrial Machines and Processes," *Proceedings*, vol. 2, no. 13, p. 781, Dec. 2018; doi: 10.3390/proceedings2130781

PTB measurement system: SmartUp Unit (SUU)



MS5837

Temperature	1 Hz
Air Pressure	1 Hz

MPU9250

X Acceleration	1000 Hz
Y Acceleration	1000 Hz
Z Acceleration	1000 Hz
X Angular speed	1000 Hz
Y Angular speed	1000 Hz
Z Angular speed	1000 Hz
X Magnetic flux density	100 Hz
Y Magnetic flux density	100 Hz
Z Magnetic flux density	100 Hz
Temperature	1000 Hz






BMA280

X Acceleration	2000 Hz
Y Acceleration	2000 Hz
Z Acceleration	2000 Hz

Kistler 8712A5M1 (ZeMA)


Z Acceleration	100 kHz
----------------	---------

Extension of the ZeMA testbed




Preprocessing of the SUU data

- Starting point: lifetime measurement of approx. 370h with continuous time series signal in which individual cycles need to be detected
- Linking between both measurement systems: trigger signal of the ZeMA testbed indicates beginning of a cycle
- Timestamped SUU raw data must be interpolated as oscillator of the low-cost system is not on point
- Preprocessing seems to be a straightforward process




Problems during preprocessing




no trigger


no data




40s timejumps




Automated Machine Learning Toolbox – Training




Automated Machine Learning Toolbox – Training




Lifetime Estimation (Results for 1kHz)



High-end,
1% target steps



Low-end, cubic,
1% target steps



Low-end, cubic,
10% target steps

Motivation – Why use uncertainty propagation in the ML toolbox?


- Basic metrological principles: Measurement uncertainties, calibration and thus traceability to the International System of Units (SI)
- If decisions are based on measurements, it is important to have high quality information of the results
- Measurement uncertainty of the used sensors
→ Express reliability of the ML results of the toolbox
- Automated ML toolbox does not take measurement uncertainty into account

GUM – an introduction

- *Guide to the Expression of Uncertainty in Measurement* (GUM), first published 1995
- Basis for the international comparison of measurement results
- Measurement result only complete with indication of measurement uncertainty
- Provides information for the calculation of measurement uncertainty
- Most common equation for uncertainty propagation are based on the *Law of Propagation of Uncertainty* (LPU)

$$u_c(y) = \sqrt{\sum_{i=1}^N \left(\frac{\partial f}{\partial x_i} \right)^2 u^2(x_i) + 2 \sum_{i=1}^{N-1} \sum_{j=i+1}^N \frac{\partial f}{\partial x_i} \frac{\partial f}{\partial x_j} u(x_i, x_j)}$$

- Partial derivatives: „sensitivity coefficients“



Extension of the automated ML toolbox

Feature extraction


- ALA^[2], BDW^[3], BFC^[4] and SM^[3]: uncertainty calculation according to GUM (Guide to the Expression of Uncertainty in Measurement)
- PCA^[2]: uncertainty calculation according to GUMS1 (GUM – Supplement 1)

Feature selection

- replace RFESVM and ReliefF by weighted Pearson, weighted Spearman, and χ^2 correlation

Classification

- LDA^[4]: uncertainty calculation according to GUMS2 (GUM – Supplement 2)




[2] Dorst, T., Eichstädt, S., Schneider, T., and Schütze, A.: Propagation of uncertainty for an Adaptive Linear Approximation algorithm, SMSI 2020, pp. 366–367, <https://doi.org/10.5162/SMSI2020/E2.3>, 2020.

[3] will be published soon

[4] Eichstädt, S. and Wilkens, V.: GUM2DFT—a software tool for uncertainty evaluation of transient signals in the frequency domain, Measurement Science and Technology, 27, <https://doi.org/10.1088/0957-0233/27/5/055001>, 2016.

Summary and outlook

- ZeMA testbed for electromechanical cylinders and its extension with the SmartUp Unit
- Preprocessing revealed data problems → Never blindly trust new data, always include plausibility heuristics
- Automated ML toolbox with uncertainty propagation according to the GUM for uncertain measurement values



Acknowledgement



Part of this work has been developed within the Joint Research project 17IND12 Met4FoF of the European Metrology Programme for Innovation and Research (EMPIR). The EMPIR is jointly funded by the EMPIR participating countries within EURAMET and the European Union.

**Thank you for
your attention!**

**Center for Mechatronics and Automation Technology
(ZeMA gGmbH)**

Gewerbepark Eschberger Weg 46, Geb. 9

D-66121 Saarbrücken

Tel +49 (0) 6 81 - 85 787 - 452

Mail t.dorst@zema.de